

Side Graphic Installation

		
<p>1) Tools needed: Spray bottle, razor blade or scissors, squeegee, blow dryer or heat gun, tape measure, masking tape and a friend to help, Clean entire surface of vehicle thoroughly. Mix a gallon or so of water with a few drops of dishwashing liquid works fine.</p>	<p>2) . Tape the graphic to vehicle to give you an idea of where it's going to go. Use the masking tape to hold in place.</p>	<p>3) When your satisfied on the position of the graphic apply two vertical masking tape on the center of the graphic to create a center hinge. Make sure the center vertical tape is on good this is very important.</p>
		
<p>4) Thoroughly wet the entire area of vehicle that is going to receive graphic with water solution. TRY NOT TO GET THE WAX PAPER WET.</p>	<p>5) Separate the transfer w/ the graphic from the waxed paper and spray the sticky side of the graphic just in case it accidentally sticks to the vehicle or to its self.</p>	<p>6) Cut away the waxed backing paper.</p>
		
<p>7) Starting from the center apply the graphic to the vehicle. Initially use light strokes with the squeezing the graphic in to position. The transfer tape will protect the Decal during this process.</p>	<p>8) Starting at the center re-squeegee using firm strokes force the fluid out. Take your time, because if not enough solution is removed from under the Decal, it will not adhere to the surface enough to allow the easy removal of the transfer tape.</p>	<p>9) Transfer the center vertical tape to the side that you've just done.</p>
		
<p>10) Remove the waxed paper from the other side and spray it with the solution</p>	<p>12) Just repeat the process to the other side.</p>	
		
<p>13) Wait for 10 - 30 min. then slowly peel the transfer tape back at an angle.</p>	<p>14) Trim all side moldings, doors jams, handles, gas tank cover and any other parts.</p>	<p>15) You can use a heat gun or a hair dryer to mold the ends to shape.</p>